


## Installation Instruction

### Subbase

The substrate must be frost-proof and level.

Two 150 mm deep holes are drilled diagonally for the installation of the 5/4" metal pipes as stable anchoring.

The pipes must be glued into the holes using polyurethane adhesive.



This allows the EUROFLEX® cubes to be installed on a load-bearing compacted substructure directly in a prepared fresh concrete bed (C12/15).

Cubes without the use of ground anchors can be fully bonded to EUROFLEX® fall protection slabs or corresponding wet pour surfaces.



All information without guarantee, subject to change. The installation instruction is not subject to any change service. Each current and valid from can be recalled at [www.kraiburg-relastec.com/euroflex/](http://www.kraiburg-relastec.com/euroflex/)



In order to avoid different discolorations caused by sunlight, please always cover the goods always cover the product completely with the UV protection film (as supplied by the factory) until installation.

### Bonding instructions

Adhesive requirement: 1 cartridge for 2 cubes full-surface bonding

#### Adhesive:

We recommend the Ottocoll P83 (grey) or Ottocoll M 500 (red) adhesive available from us. The warranty is void if other untested adhesives are used.

#### Work preparation:

The surfaces must be clean, dry and free of grease.

Bonding: Apply the material to the substrate from the glue gun. The application thickness depends on the nature of the materials to be bonded. Insert and press on the mating material within 10 minutes. The curing time depends on the layer thickness and air humidity.

Processing temperature: +5°C - +40°C, skin formation time at 23°C: approx. 20 minutes, Curing time at 23°C: approx. 24 hours

All information without guarantee, subject to change. The installation instruction is not subject to any change service. Each current and valid from can be recalled at [www.kraiburg-relastec.com/euroflex/](http://www.kraiburg-relastec.com/euroflex/)

page 2 of 2