


**Substructure**

The substructure must be frost-stable and level.



**Installation**

The EUROFLEX® cubes with the 4 pressed-in ground anchors can be placed on one load-bearing compacted substructure directly into a prepared fresh concrete bed (C12 / 15) to be installed.

Cubes without ground anchors can placed on EUROFLEX® fall protection slabs or corresponding in-situ surfaces are glued.





To avoid colour variations due to differences in sunlight exposure, leave the UV protection film on the product as supplied until just prior to installation.

### Gluing instructions

Glue requirement: 1 cartridge for 2 cubes full-surface gluing

#### Adhesive:

We recommend the adhesive Ottocoll P83 (gray) or Ottocoll M 500 (red), which can be obtained from us. The warranty is void if other adhesives that have not been tested are used.

#### Work preparation:

The surfaces must be clean, dry and free of grease.

Gluing: Apply the material from the glue gun to the substrate. The application thickness depends on the nature of the materials to be bonded. Insert the counter material within 10 minutes and press it on. The curing depends on the layer thickness and the humidity.

Processing temperature: + 5 ° C - + 40 ° C, skin formation time at 23 ° C: approx. 20 minutes, Hardening time at 23 ° C: approx. 24 hours